



DETAIL - TRAFFIC TREATMENT FOR TREES IN 600mm SOIL PROFILE

NOTES:

- CULTIVATE NATURAL EARTH SUB-GRADE AND REMOVE ALL BALLAST, AGGREGATE, BLUESTONE, CONCRETE, ASPHALT OR OTHER ROAD CONSTRUCTION MEDIA FROM TRAFFIC TREATMENT PROFILE (MINIMUM DEPTH 600mm).
 - SUPPLY AND SPREAD TOPSOIL 200mm (MINIMUM) OVER TRAFFIC TREATMENT TO MEET LEVEL 100mm BELOW EDGE. N.B. ALL TRAFFIC TREATMENTS MUST CENTRALLY MOUND TOPSOIL @ 50mm HEIGHT.
 - CULTIVATE TOPSOIL INTO 100mm OF THE NATURAL EARTH SUB-GRADE MEDIA. IF NATURAL EARTH PROFILE IS BELOW 700mm SUB-GRADE, FILL TRAFFIC TREATMENT WITH 600mm SANDY LOAM TOPSOIL..
 - SUPPLY AND SPREAD MULCH 20mm ORGANIC / RECYCLED TIMBER (FINES SCREENED: N.B. NEVER USE TAN-BARK)
- (ALL MATERIALS TO BE APPROVED BY COUNCIL SUPERINTENDENT PRIOR TO PLACEMENT).

Yarra Standard:YSD713 Drawing Title:

TYPICAL DETAILS - TRAFFIC
TREATMENT SUPPORTING TREES

Scale A4 @ 1:1000

REV	DATE	DRAWN BY
A	12/07/18	CM

